

## OMNICHECK 360 DETECTION SYSTEM TROUBLE SHOOTING MANUAL



## Contents

OMNICHECK 360 DETECTION SYSTEM TROUBLE SHOOTING MANUAL.....	1
REVISION HISTORY .....	3
INTRODUCTION .....	4
REJECTING ON INSPECTION (FALSE REJECT) .....	4
NO REJECTION OR INSPECTION .....	6
SERVO FAILURE OR MANUAL SERVO MOVEMENT .....	7

## REVISION HISTORY

REV.	DATE	AUTHOR	APPROVED BY	DESCRIPTION
1.0	Jan 12 2020	Adam Szekely	Adam Szekely	Document Creation

## INTRODUCTION



This manual is used to figure out the most likely causes of system malfunction. It is assumed that the following pre inspection has been conducted.



1. Trigger system is operational and triggering on the bottle cap
2. Lights cameras and system is operational
3. Protective panel inside the tunnel has been cleaned once a day with
4. Rejector is operational air to the rejector is sufficient.

Trouble shooting is broken down into 3 sections





1. False reject the system is rejecting good bottles
2. False accept the system is not rejecting bad bottles
3. Servo system malfunction

## REJECTING ON INSPECTION (FALSE REJECT)

STEP	DESCRIPTION	DIAGRAM
1	Verify that it is a legitimate false reject by examining the dashboard screen last reject and the bottle. Ensure you have the SAT fail limits for all inspections. i.e. high cap must be 3mm above the nominal correctly torqued cap.	 <p>500 ml, Clear Label</p> <p>TOTAL COUNT 23438 TOTAL FAIL COUNT 7750 REJECT % 33.07 BOTTLES PER MINUTE 60</p> <p>CAMERA 1 FAIL COUNT 481 CAMERA 2 FAIL COUNT 59 CAMERA 3 FAIL COUNT 660 CAMERA 4 FAIL COUNT 15 CAMERA 5 FAIL COUNT 13 CAMERA 6 FAIL COUNT 12</p> <p>Monday, April 20, 2020 8:28 PM Administrator</p> <p>MAIN MENU RESET ALL COUNTERS</p> 
2	Identify which camera is rejecting this bad bottle. NOTE: Camera 1 inspects for cap and fill Camera 2 inspects for cap only Camera 3 inspects for cap only Camera 4 inspects for label only Camera 5 inspects for label only Camera 6 inspects for label only Camera 7 inspects for color only.	<p>CAMERA 1 FAIL COUNT 481 CAMERA 2 FAIL COUNT 59 CAMERA 3 FAIL COUNT 660 CAMERA 4 FAIL COUNT 15 CAMERA 5 FAIL COUNT 13 CAMERA 6 FAIL COUNT 12</p>



STEP	DESCRIPTION	DIAGRAM
3	Navigate to the respective camera and place the bad bottle through the inspection. Compare the calculated value with the threshold. Adjust the threshold, as necessary. The highlighted Yellow is the value seen by the camera should be in the middle of the min and max.	 <p>LEFT CAP HEIGHT 137  MIN LEFT CAP HEIGHT 110  MAX LEFT CAP HEIGHT 165  RIGHT CAP HEIGHT 138  MIN RIGHT CAP HEIGHT 110  MAX RIGHT CAP HEIGHT 165</p>
4	Ensure the position of the inspection window is correct. If not adjust the positions as required to find the correct edge / shape. NOTE when adjusting inspection zones, it is possible that the system will reject everything, disable rejection for the camera you are adjusting. Then do not forget to enable rejection after adjustments complete.	
5	Observe production and verify operation	N/A

## NO REJECTION OR INSPECTION

STEP	DESCRIPTION	DIAGRAM
1	<p>Verify that it is a legitimate bad product by examining the dashboard screen last reject and the bottle.</p> <p>Ensure you have the SAT fail limits for all inspections. i.e. high cap must be 3mm above the nominal correctly torqued cap.</p>	
2	<p>Ensure that you see an increase in throughput values on the dashboard screen if not the system is not triggering, or the encoder is failed</p>	
3	<p>If the system sees the bad bottle but the rejector does not active, ensure that rejection is enabled for that camera yellow shaded button needs to be red.</p>	
4	<p>If the rejector is enabled in the software, ensure the Air regulator is on and rejector is functioning properly</p>	

## SERVO FAILURE OR MANUAL SERVO MOVEMENT

Use this procedure when the servo cannot be moved automatically, or a servo motor / drive failure occurred, and replacement part is not in stock.

STEP	DESCRIPTION	DIAGRAM
1	Place the system into manual mode by unplugging the power to the servo drive. See the unplugged power cable in the picture	
2	Using your finger rotate the shaft until the camera bracket aligns with the mark left by the installer during installation.	
3	On every recipe change or power, up / down the failed servo messages must be accepted by clicking OK on the screen	